

COUNTAX™

SERVICE BULLETIN

09-T6-17

DATE: 7/6/09

MODELS CONCERNED: A, D & K Series

CONCERN: Thrust washer change on K62 & K66 Transmission

Part Numbers

K62 & K66 Thrust Washer Kit: 405067500

K62 & KK Thrust Washer: 307191901 x2

A2050 Wheel Spacer: 183018501 x2

Washer: 089423500 x2

The Thrust washer is placed over the axle first (both sides), then the washer followed by the spacer as figure 1 shows. The wheel is then placed on as normal making sure a key is used and the axle is lubricated.




Figure 1: K62 & K66 Thrust washer kit



Please contact COUNTAX service department for any further information