Parts Manual

Mfg. No: 286707-0160-01

Copyright © Briggs and Stratton. All Rights reserved

17-Aug-2018

Model Components

	Page
Air Cleaner, Muffler	4
Alternator, Ignition, Wires	8
Blower Housing, Rotating Screen	10
Carburetor, Carburetor Overhaul Kit	12
Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft, Piston/Rings/	18
Electric Starters	24
Fuel, Brackets, Controls, Springs	28
Replacement Engine	32
Rewind Starter, Flywheel	33

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Air Cleaner, Muffler

Mfg. No: 286707-0160-01





Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Air Cleaner, Muffler

REF NO	PART NO	QTY	DESCRIPTION
11	692253		Tube-Breather
50	691711		Manifold-Intake
51A	272554S		Gasket-Intake
53	690227		Stud -(Carburetor)
54	690953		Screw -(Intake Manifold)
167	692297		Seal-Air Cleaner Nut
176	691917		SEAL, O-Ring -(Air Cleaner Base)
237	690409		Retainer-Muffler Guard
263	691083		Screw -(Muffler Guard Retainer)
298	691808		Locknut-Muffler/Elbow
300	691874		Muffler
300A	498984S		Muffler
300B	391569S		Muffler
301	93768		Pipe-Exhaust
303	690281		Elbow-Exhaust
344	693675		Screw -(Cable Clamp)
346	690661		SCREW -(Spark Arrestor)
445	496894S		Filter-A/C Cartridge
467	691668		Knob-Air Cleaner Cover
607	690703		Screw -(Air Cleaner Brace)
607A	691693		SCREW -(Air Cleaner Brace)
613	691416		SCREW -(Muffler)
613A	691693		SCREW -(Muffler)
613B	692198		Screw -(Muffler)
654	690958		NUT -(Carburetor)
676	396903		DEFLECTOR, Muffler
676A	393761		Deflector-Muffler
676B	397630		Deflector-Muffler
677	690661		SCREW -(Muffler Deflector)
725	690420		Shield-Heat -(Muffler)
832	692361		Guard-Muffler
836	690367		Screw -(Muffler Guard)
875	696129		Base-Air Cleaner
883	692236		GASKET, Exhaust
967	272403S		Filter-Pre Cleaner
968	691916		Cover-Air Cleaner
971	691108		SCREW -(Air Cleaner Base to Carburetor/Throttle Body) -Used After Code Date 98091300
971	692198		Screw -(Air Cleaner Base to Carburetor/Throttle Body) -Used Before Code Date 98091400

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Air Cleaner, Muffler

Mfg. No: 286707-0160-01





Not For Reproduction

Air Cleaner, Muffler

REF NO	PART NO	QTY	DESCRIPTION
994	392390		Arrestor-Spark

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Alternator, Ignition, Wires

Mfg. No: 286707-0160-01

DC ONLY	DUAL CIRCUIT	TRI CIRCUIT	10/16 AMP
474 877A 1059	474A 877 1059	474B 877B 1059	474C 877C 1059
578	878	878A	



















Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Alternator, Ignition, Wires

REF NO	PART NO	QTY	DESCRIPTION
333	492341		Armature-Magneto
334	691061		SCREW -(Magneto Armature)
356	690807		Wire-Stop
356A	398808		WIRE, Stop (30" Cut To Required Length)
356D	690799		Wire-Stop
474	696578		Alternator -(DC Only)
474A	696459		Alternator -(Dual Circuit)
474B	696457		Alternator -(Tri Circuit)
474C	696458		Alternator -(10-16 AMP.)
493	694475		Bracket-Mounting
501	691185		Regulator
501A	691188		Regulator
526	690326		SCREW -(Regulator)
526A	692198		Screw -(Regulator)
578	692306		WIRE ASSEMBLY
729	690596		Clip-Wire
729C	691335		Clip-Wire
789A	692037		HARNESS, Wiring
851	493880S		TERMINAL, Spark Plug
877	393456		WIRE/CONNECTOR, Alternator -(Dual Circuit)
877A	393814		Wire/Connector-Alternator
877B	393537		Wire/Connector-Alternator
877C	399916		Wire/Connector-Alternator
878	398661		Harness-Alternator
878A	691955		Harness-Alternator
920	691656		SOLENOID, Starter
1054	280275		Tie-Cable
1059	698516		KIT, Screw/Washer -(Alternator)
1119	691183		SCREW -(Alternator)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Blower Housing, Rotating Screen

Mfg. No: 286707-0160-01











1036 EMISSIONS LABEL

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Blower Housing, Rotating Screen

REF NO	PART NO	QTY	DESCRIPTION
37	690456		Guard-Flywheel
73	691191		Screen-Rotating
73A	691748		Screen-Rotating
74	690345		Screw -(Rotating Screen)
74A	691655		Screw -(Rotating Screen)
75	690582		Washer -(Flywheel)
78	690661		SCREW -(Flywheel Guard)
304	494268		Housing-Blower -(Red) -Used Before Code Date 93071900
305	692198		Screw -(Blower Housing)
305A	692127		Screw -(Blower Housing)
318A	691082		Screw -(Mounting Bracket)
332	690662		Nut -(Flywheel)
455	691173		Cup-Flywheel
455A	695113		CUP, Flywheel
493A	692825		Bracket-Mounting
563A	690370		Screw -(Debris Screen Guard)
668A	691323		Spacer
727	490324		Cover-Starter Drive
732	691002		Screw -(Starter Drive Cover)
934	691058		Screw -(Fan Retainer)
949A	397530		Guard-Debris Screen
1005	691905		Fan-Flywheel -Used Before Code Date 99102500
1005	794436		Fan-Flywheel -Used After Code Date 99102400
1006	690452		Retainer-Fan
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1044	698139		SCREW -(Flywheel)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

Mfg. No: 286707-0160-01

NIKKI



WALBRO



Not For Reproduction







WALBRO **NIKKI**



Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

REF NO	PART NO	QTY	DESCRIPTION
51	692284		Gasket-Intake
93	690602		Bushing-Throttle Shaft
94	498030		Kit-Idle Mixture
94A	494383		Kit-Idle Mixture
95	691636		Screw -(Throttle Valve)
95A	690718		SCREW -(Throttle Valve)
98	495800		Kit-Idle Speed
98A	694907		Kit-Idle Speed
104	690525		Pin-Float Hinge
104A	694918		PIN, Float Hinge
105	231855S		Valve-Float Needle
105A	696136		VALVE, Float Needle
106	691780		Seat-Inlet -(Pump Feed Carburetor) -Used After Code Date 92071900
106	690577		Seat-Inlet -(Gravity Feed Carburetor) -Used After Code Date 92071900
106	691901		Seat-Inlet -(Gravity Feed Carburetor) -Used Before Code Date 92072000
108	690467		Valve-Choke
108A	692344		Valve-Choke
108B	694923		Valve-Choke
117	690880		Jet-Main -(Standard)
121	497535		Kit-Carburetor Overhaul -(LMT 1, 2, 3, 7, 37, 77, 157, 161)
121	499220		Kit-Carburetor Overhaul -(LMT 92, 93, 94, 95, 96, 108, 111, 162, 165, 169)
121	499231		Kit-Carburetor Overhaul -(LMT 97, 99, 133, 135, 136, 157, 158, 159, 160, 166, 168)
121	697884		Kit-Carburetor Overhaul -(696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906)
121	497481		Kit-Carburetor Overhaul -(LMT 63, 65, 66)
121A	694930		Kit-Carburetor Overhaul -(Nikki Carburetor)
125	498027		Carburetor -(Walbro) (Gravity Feed)
125	499158		Carburetor -(Walbro)(Pump Feed)
125	698171		Carburetor -(696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906)
125A	699831		Carburetor -(Nikki Carburetor)
127	695005		Plug-Welch
127	694524		Plug-Welch -(696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906)
127A	694916		Plug-Welch
130	690468		Valve-Throttle -(LMT 111, 169)
130B	691750		Valve-Throttle
131	790901		Kit-Throttle Shaft -(LMT 111, 169)
131B	694909		Kit-Throttle Shaft -(Nikki Carburetor)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

Mfg. No: 286707-0160-01

NIKKI





WALBRO









WALBRO **NIKKI**



Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

REF NO	PART NO	QTY	DESCRIPTION
133	494381		Float-Carburetor
133A	694914		FLOAT, Carburetor
134	494788		Kit-Needle/Seat -(LMT 5, 6)
137	281165S		Gasket-Float Bowl
137A	694920		Gasket-Float Bowl
141	790905		Kit-Choke Shaft -(Manual Choke)
141A	790902		Kit-Choke Shaft -(Choke A Matic)
141B	694913		Kit-Choke Shaft
142	697592		Nozzle-Carburetor -(696160, 696162, 696164, 696166, 697212, 697213, 697214, 697906)
142	497568		Nozzle-Carburetor -(LMT 97, 99, 100)
142	497860		Nozzle-Carburetor -(LMT 63, 65, 66, 108, 111, 133, 135, 136)
142	498545		Nozzle-Carburetor -(LMT 108, 111)
142	499037		Nozzle-Carburetor -(LMT 162, 165, 169)
142	499039		Nozzle-Carburetor -(LMT 166, 167, 168)
142	691425		Nozzle-Carburetor -(LMT 5, 6)
142	691434		Nozzle-Carburetor -(LMT 92, 93, 94, 96)
143	498258		Nozzle-Carburetor -(High Altitude) (LMT 63, 65, 66, 108, 111, 133, 135, 136)
143	499040		Nozzle-Carburetor -(High Altitude) (LMT 166, 167, 168)
143	497567		Nozzle-Carburetor -(High Altitude) (LMT 5, 6)
143	497737		Nozzle-Carburetor -(High Altitude) (LMT 92, 93, 94, 96)
143	497970		Nozzle-Carburetor -(High Altitude) (LMT 97, 99, 100)
147	497472		Jet-Pilot -(LMT 1, 2, 3, 4, 5, 7, 37, 38, 39, 40, 41, 77, 78, 79, 80, 81)
147A	694927		Jet-Pilot
173	694926		Valve-Idle Mixture
186	692317		Connector-Hose
231	691636		Screw -(Choke Valve)
231A	690718		SCREW -(Choke Valve)
276	692255		Washer-Sealing
276A	690997		Washer-Sealing
633	695414		Seal-Choke/Throttle Shaft
634	690801		Spring/Seal Assembly
634A	690802		Spring/Seal Assembly
634B	694912		Spring/Seal Assembly
692	690572		Spring-Detent
950	691657		Screw-Float Bowl
950A	694919		SCREW, Float Bowl
955	694924		Plug-Carburetor -(Idle Chamber)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

Mfg. No: 286707-0160-01

NIKKI



WALBRO









WALBRO **NIKKI**



Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Carburetor, Carburetor Overhaul Kit

REF NO	PART NO	QTY	DESCRIPTION
955A	694921		Plug-Carburetor -(Pilot Jet)
975	495933		Bowl-Float
975A	694908		Bowl-Float
977	690192		Gasket Set-Carburetor
977A	694931		Gasket Set-Carburetor
987	691326		Seal-Throttle Shaft
1091	691333		Cap-Limiter

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft,

Mfg. No: 286707-0160-01





















1319 WARNING LABEL



REQUIRED *when replacing parts with warning labels affixed.*

1330 REPAIR MANUAL



1058 OPERATOR'S MANUAL



322A











358 ENGINE GASKET SET



1095 VALVE GASKET SET





Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft,

REF NO	PART NO	QTY	DESCRIPTION
1	496413		Cylinder Assembly
2	399265		Kit-Bushing/Seal -(Magneto Side)
3	391086S		SEAL, Oil -(Magneto Side)
4	494238		Sump-Engine
5	494240		Head-Cylinder
6	691261		WASHER -(Cylinder Head)
7	271866S		Gasket-Cylinder Head
8	495735		Breather Assembly
9	27803S		Gasket-Breather
10	691666		Screw -(Breather Assembly)
11	692253		Tube-Breather
12	692406		Gasket-Crankcase -(.005" Thick)
12	692226		Gasket-Crankcase -(.015" Thick)(Standard)
12	692405		Gasket-Crankcase -(.009" Thick)
13	690904		Screw -(Cylinder Head)
14	691690		Stud -(Cylinder Head) (Used In Positions 5 And 6)
15	690946		PLUG, Oil Drain
15A	691680		PLUG, Oil Drain
16	693944		Crankshaft -Used After Code Date 95080200
16B	693653		Crankshaft -Used Before Code Date 95080100
20	291675S		Seal-Oil -(PTO Side)
22	692125		SCREW -(Crankcase Cover/Sump)
24	222698S		KEY, Flywheel
25	499284		Piston Assembly -(Standard) -Used Before Code Date 01060700
25	499292		Piston Assembly -(.020" Oversize) -Used Before Code Date 01060700
25	696397		Piston Assembly -(Standard) -Used After Code Date 01060600
25	696399		Piston Assembly -(.020" Oversize) -Used After Code Date 01060600
25	696400		Piston Assembly -(.030" Oversize) -Used After Code Date 01060600
26	392331		Ring Set -(Standard)(Chrome) -Used Before Code Date 01060700
26	499996		Ring Set -(Standard) -Used Before Code Date 01060700
26	499998		Ring Set -(.020" Oversize) -Used Before Code Date 01060700

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft,

Mfg. No: 286707-0160-01

















1319 WARNING LABEL



REQUIRED *when replacing parts with warning labels affixed.*

1330 REPAIR MANUAL



1058 OPERATOR'S MANUAL

















358 ENGINE GASKET SET



1095 VALVE GASKET SET





Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

REF NO	PART NO	QTY	DESCRIPTION
26	696403		Ring Set -(Standard) -Used After Code Date 01060600
26	696405		Ring Set -(.020" Oversize) -Used After Code Date 01060600
27	691299		Lock-Piston Pin -Used After Code Date 95101500
27	691792		Lock-Piston Pin -Used Before Code Date 95101600
28	299691		Pin-Piston -(Standard) -Used Before Code Date 95101600
28	498319		Pin-Piston -(Standard) -Used After Code Date 95101500
28	498320		Pin-Piston -Used After Code Date 95101500
29	494504S		Rod-Connecting -(Standard)
29	495490		Rod-Connecting -(.020" Undersize)
31	222299		Lock-Rod Screw
32	690356		Screw -(Connecting Rod) (1 7/8" Long)
32A	690348		Screw -(Connecting Rod) (1 5/8" Long)
33	262246S		Valve-Exhaust
34	262247S		Valve-Intake
35	691605		Spring-Valve -(Intake)
36	691597		Spring-Valve -(Exhaust)
40	690656		Retainer-Valve -(Intake)
40A	691939		Retainer-Valve -(Exhaust)
42	494553		Keeper-Valve
43	691968		SLINGER, Governor/Oil
45	691811		Tappet-Valve
46	697668		Camshaft
51A	272554S		Gasket-Intake
111	691679		Pin-Retainer
146	691639		KEY, Woodruff
176	691917		SEAL, O-Ring -(Air Cleaner Base)
287	691002		Screw -(Dipstick Tube)
306	698477		Shield-Cylinder
307	691003		SCREW -(Cylinder Shield)
308	698476		Cover-Cylinder Head
322	692198		Screw -(Cylinder Head Cover)
322A	691681		SCREW -(Cylinder Head Cover)
337	802592S		Plug-Spark
349	691105		Nut -(Cylinder Head Cover)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft,

Mfg. No: 286707-0160-01





















1319 WARNING LABEL



REQUIRED *when replacing parts with warning labels affixed.*

1330 REPAIR MANUAL



1058 OPERATOR'S MANUAL













358 ENGINE GASKET SET



1095 VALVE GASKET SET





Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Crankcase Cover/Sump, Engine Gasket Set, Cylinder, Oil, Valve Gasket Set, Crankshaft,

REF NO	PART NO	QTY	DESCRIPTION
357	691483		KEY, Drive Pulley
358	494241		Gasket Set-Engine
383	89838S		Wrench-Spark Plug
441	224390		Bracket-Oil Fill
449	691678		SCREW -(Oil Fill Bracket)
523	692014		Dipstick
524	281370S		Seal-Dipstick Tube
525	691398		Tube-Dipstick
525A	495768		Tube-Dipstick
552	491986		Bushing-Governor Crank
635	66538S		BOOT, Spark Plug
668	690510		Spacer
691	692407		SEAL, Governor Shaft
709	262243		Eccentric
718	690959		PIN, Locating
733	698139		SCREW -(Crankshaft Extension)
741	691284		Gear-Timing
757	691714		Link-Counterweight
758	692423		Counterweight
759	691239		Pin-Counterweight
761	691096		Screw -(Counterweight)
810	691779		Extension-Crankshaft
842	691870		Seal-O Ring -(Dipstick Tube)
847	496415		Dipstick/Tube Assembly
847A	490474		Dipstick/Tube Assembly
869	691802		Seat-Valve -(Intake)
870	691844		Seat-Valve -(Exhaust)
871	261961		Bushing-Valve Guide
871	231218		Bushing-Valve Guide -(Brass)
883	692236		GASKET, Exhaust
1058	274787		Operator's Manual
1095	498539		Gasket Set-Valve
1319	794467		LABEL, Warning
1330	270962		Repair Manual

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved











NOTE: *For Replacement Starter Motor, See Reference 309.*

Not For Reproduction

Electric Starters

REF NO	PART NO	QTY	DESCRIPTION
309	497595		Motor-Starter -(3 5/8" Housing Length)
309	499521		Motor-Starter -(4 3/8" Housing Length)
309	693551		Motor-Starter -(3 5/8" Housing Length For Steel Ring Gear Only)
309	693552		Motor-Starter -(4-3/8" Housing Length For Steel Ring Gear Only)
309A	-----		Motor-Starter -(For Replacement Starter Motor, See Reference 309, Previous Page)
310	690323		BOLT -(Starter Motor)
310	691263		Screw -(Starter Motor) (4 3/8" Housing Length)
311	497608		Brush Set
311A	395538		Brush Set -(For 3 5/8" Housing Length)
403	690288		Washer -(End Cap)
462	691261		WASHER -(Starter Cable)
503	691532		STRAP, Starter
510	693699		DRIVE, Starter -(Used With Steel Ring Gear)
510A	696541		Drive-Starter -(Used With Aluminum And Plastic Ring Gears)
510B	696540		Drive-Starter
513	692024		CLUTCH, Drive
544	692034		Armature-Starter -(3 5/8" Housing Length)
544A	490309		Armature-Starter -(4 3/8" Housing Length)
544A	390837		Armature-Starter -(3 5/8" Housing Length)
579	691029		NUT -(Starter Cable)
697	690372		Screw -(Starter Motor) (Drive Cap)
697A	691058		Screw -(Starter Motor) (Drive Cap)
729A	691224		CLIP, Wire
729B	224723		Clip-Wire
783	693713		Gear-Pinion -(DC)(10-16 AMP)
783A	695708		Gear-Pinion
797	693167		NUT -(Brush Retainer)
801	691283		CAP, Drive
802	691286		CAP, End
802A	395537		Cap-End -(For 3 5/8" Housing Length)
803	-----		Housing-Starter -(3 5/8" Housing Length)(Service with Corresponding Reference 309)
803	XX		Housing-Starter -(4 3/8" Housing Length)(Service with Corresponding Reference 309)
803A	398159		Housing-Starter -(For 3 5/8" Housing Length)
803A	494205		Housing-Starter -(For 4-3/8" Housing Length)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Mfg. No: 286707-0160-01











NOTE: *For Replacement Starter Motor, See Reference 309.*

Not For Reproduction

Electric Starters

REF NO	PART NO	QTY	DESCRIPTION
876	696539		Kit-Pinion Spring
896	691641		Pin-Drive Retainer
1051	691265		RING, Retaining
1083	691626		Nut -(End Cap)
1083A	690958		NUT -(End Cap) (Serrated)
1090	691293		RETAINER, Brush

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Mfg. No: 286707-0160-01



Not For Reproduction

Fuel, Brackets, Controls, Springs

REF NO	PART NO	QTY	DESCRIPTION
179	692331		Screw -(Fuel Tank Strap)
182	690443		Bracket-Fuel Tank -(Right Hand)
182A	692535		Bracket-Fuel Tank -(Left Hand)
183	698459		Strap-Fuel Tank -(Right Hand)
183A	692030		Strap-Fuel Tank -(Left Hand)
186A	691609		Connector-Hose
187	791766		LINE, Fuel -(Cut To Required Length)
187A	791806		Line-Fuel -(Formed)(21" Long)(Cut To Required Length)
187C	697907		Line-Fuel -(Formed)(Cut To Required Length)
188	691693		SCREW -(Control Bracket)
202	691841		LINK, Mechanical Governor
203	691381		Crank-Bell
209	692208		Spring-Governor -(Green)
216	691840		LINK, Choke
216A	690574		Link-Choke
216B	691281		Link-Choke
222	694042		Bracket-Control
222A	692002		Bracket-Control
227	691374		LEVER, Governor Control
232	691842		SPRING, Governor Link
240	298090S		Filter-Fuel -(Red)
240	394358S		FILTER, Fuel -(White)
265	691024		CLAMP, Casing
267	690804		Screw -(Casing Clamp)
268	691025		CASING, Control Wire -(Cut To Required Length)
269	691026		WIRE, Control -(Cut To Required Length)
270	691027		NUT -(Control Wire Casing)
271	691028		Lever-Control
359	691077		Washer -(Ground Terminal)
373	691612		NUT -(Ground Terminal)
385	692198		Screw -(Fuel Pump)
387	808656		PUMP, Fuel
404	691691		WASHER -(Governor Crank)
450	690259		Washer -(Fuel Tank Bracket)
480	690664		Screw -(Tube Clamp)
505	691251		NUT -(Governor Control Lever)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Mfg. No: 286707-0160-01



Not For Reproduction

Fuel, Brackets, Controls, Springs

REF NO	PART NO	QTY	DESCRIPTION
507	691972		Insulator
520	691084		Terminal-Ground
527	690394		Clamp-Tube
559	690661		SCREW -(Remote Choke Stop)
562	691119		BOLT -(Governor Control Lever)
601	791850		CLAMP, Hose
614	691620		PIN, Cotter
615	93307		Retainer-Governor Shaft
616	692012		CRANK, Governor
621	692310		Switch-Stop
628	690661		SCREW -(Fuel Pump Bracket) (13/32" Long)
628A	692198		Screw -(Fuel Pump Bracket) (2 5/16" Long)
674	691058		Screw -(Fuel Tank Bracket)
707	690279		Nut -(Fuel Tank Strap)
725A	690403		Shield-Heat -(Fuel Line)
788	690458		Bracket-Fuel Pump
846	690371		Washer -(Fuel Tank Strap)
918	393815		Hose-Vacuum -(Cut To Required Length)
957	493988S		Cap-Fuel Tank
958	698183		VALVE, Fuel Shut Off(PLT)
972	390225		Tank-Fuel -(3 Quart Tank)

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Replacement Engine

REF NO	PART NO	QTY	DESCRIPTION
	2199073026	1	Replacement Engine
	-----		Top No-Load Speed: 3200 -Trim: ALL
	-----		Service Note: If the replacement engine supersedes to or is a Model 210000 series engine, refer to the illustrations located after the conversion data for this model series. The overall dimensions which differ, are shown in the illustrations.
	-----		Service Note: If after making a visual inspection and it is determined the Model 210000 series engine cannot be used because of equipment interference, the original engine should be repaired with a short block and/or individual parts.
	-----		Service Note: Transfer Alternator Assembly from original engine to replacement engine.

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Rewind Starter, Flywheel

Mfg. No: 286707-0160-01















Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Rewind Starter, Flywheel

REF NO	PART NO	QTY	DESCRIPTION
23	693556		Flywheel -(Steel Ring Gear)
55	695130		Housing-Rewind Starter
55A	393576		Housing-Rewind Starter
56	695129		PULLEY, Starter
56A	295871		Pulley-Starter
57	695131		SPRING, Rewind Starter
57A	490179		Spring-Rewind Starter
58	695132		ROPE, Starter -(59" Long)
58A	695002		Rope-Starter -(99" Long)(Cut to Required Length)
60	490652		HANDLE, Starter Rope
63	690547		Spring-Ratchet
64	691920		Adapter-Ratchet Spring
65	697725		SCREW -(Rewind Starter)
65A	690837		Screw -(Rewind Starter)
66	399671		Clutch-Starter
67	394897		Housing-Clutch
68	691604		Ball-Clutch
70	691945		Ratchet-Clutch
71	691359		Cover-Ratchet
165	693148		Nut -(Ring Gear)
363	19203		PULLER, Flywheel
456	695128		PLATE, Pawl Friction
459	281505S		PAWL, Ratchet
592	690800		Nut -(Rewind Starter)
597	691696		Screw -(Pawl Friction Plate)
608	695058		Starter-Rewind -Used After Code Date 99102400
608A	390391		Starter-Rewind -Used Before Code Date 99102500
655	691734		Anchor-Rewind Spring
678	490817		Spacer-Rewind
689	691855		SPRING, Friction
695	693109		Screw -(Ring Gear)
726	-----		Gear-Ring
726A	696537		Gear-Ring -(Aluminum)(Services Plastic Ring Gear Only)
783	693713		Gear-Pinion -(DC)(10-16 AMP)
783A	695708		Gear-Pinion
930	691904		Guard-Rewind
1051	691265		RING, Retaining

Not For Reproduction

Copyright © Briggs and Stratton. All Rights reserved

Copyright © Briggs and Stratton. All Rights reserved